

RC PRO

Remote Control for ECTIVE PRO Power Inverters



Full Control Over your Power Supply

The ECTIVE RC PRO remote control is connected to an ECTIVE PRO inverter via the supplied RJ12 cable and displays different values and statuses of the inverter and the connected system. The button on the remote control makes it easy to switch the inverter between ECO mode (battery priority mode) and UPS mode (mains priority mode).

This makes it easy to keep an eye on and to control the power supply, even if the inverter is installed in an inaccessible location.

Different data is displayed depending on which ECTIVE PRO the remote is connected to: the status of the inverter and the battery is always displayed. When connected to an ECTIVE CSI PRO, the display also indicates the status of the installed battery charger. With ECTIVE SSI PRO devices, the display additionally shows the parameters of the integrated MPPT solar charge controller.



Compatibility

The ECTIVE RC PRO remote control is only compatible with ECTIVE brand inverters that have the suffix „PRO“ in the product designation. It is not compatible with inverters from the regular ECTIVE SI, TSI, CSI and SSI series.

- ✔ ECTIVE TSI PRO
- ✔ ECTIVE CSI PRO
- ✔ ECTIVE SSI PRO

- ✘ ECTIVE SI
- ✘ ECTIVE TSI
- ✘ ECTIVE CSI
- ✘ ECTIVE SSI

Dimensions

